

Instructions for Operation

Standard LED Wands are used with and require a BCX Ultra Deluxe

1. Plug the supplied cord into the jack on the Standard LED Wand
2. Connect the other end to the "LED Wand" jack in the front panel of the BCX Ultra Deluxe
3. Select LED STD, or LED STD with another BCX Ultra Accessory
4. Run a BCX Ultra Deluxe Program